
# ATL® Safety Fuel Cell Installation Procedures SUPER CELL® SPORTS CELL®

# FOLLOW THESE STEPS IN SEQUENCE

- 1. Mount fuel cell between frame rails as far inboard as possible.
- 2. Secure fuel cell container in a recessed well with minimum 1"x 1" square steel tubing. Consult NASCAR or FIA Rule book for full installation compliance.
- 3. Do not insert fasteners through the fuel cell container as they could chafe the bladder.
- **4.** Be sure fuel pickups are positioned toward the rear of the bladder to assure positive fuel feed during acceleration.
- 5. For Circle Track racing, use the right side pickup. See Diagram #1.
- 6. For Road Circuits use two fuel pickups as shown in Diagram #2. Otherwise use left pickup on clockwise tracks and right pickup on counter clockwise tracks. Don't "T" two pickups to one pump.
- 7. For Off-Road & Drag Cars, use road course hookup as shown in Diagram #2.
- 8. The vent line should loop forward of the cell to exit as shown in Diagrams #1 and #4 (on next page). Super Cells, Sports Cells, Saver Cells and Racells have built-in vent check valves. However, a Discriminator Valve should be used in the vent line for dry-break refueling operations. Request Data Sheets DS374 and DS389 for quick-fill systems. Quick-Fill requires min. 1" dia. vent.


### DIAGRAM #1

Suggested Circle Track & Race Boat Hook Up For Left Turns Only.




### DIAGRAM #2


Suggested Road Course & Off Road Hook Up for Right & left Turns.




## **DIAGRAM** #3, (A & B)

Remote Fill and Fast Remote Fill applications.





# **DIAGRAM #4** Typical ATL Safety Fuel Cell Installation



# FITTING-PLATE MOUNTING: SUPER, SPORTS & SAVER CELLS


To mount fitting-plate assembly to fuel bladder, see Diagram #5 and:

- 1. Position Duck Foot fuel pickup and strainer underneath foam and locate in rear corners of bladder per Diagrams #1 & #2.
- 2. Holding fitting plate to within 2" of bladder, tighten swivel hose-end(s) to bulkhead fitting(s) on fitting plate.
- 3. Position gasket under plate.
- 4. Secure fitting plate to fuel cell nut-ring using the 1/4"x 28 bolts, sealing washers & break-away tabs supplied.
- 5. Tighten bolts firmly with 7/16" wrench or 5/32" allen key (40 inch lb. torque).

- 6. To remove plate -- reverse procedure. Be careful not to dislodge pickup when lifting fitting plate. Always flush cell with water before any disassembly.
- 7. Fuel fittings on ATL cells are standard "AN" type components. All matching couplings should be either "AN" aircraft type or J.I.C. hydraulic fittings (37° seat).
- 8. See also sheets #DS-403 Assembly Cutaway and #DS-447 Assembly Instructions.

CAUTION: Do not weld near fuel bladders. Excessive heat and weld spatter can cause fuel cell damage and/or create a fire.

# **DIAGRAM #5** Section View Through Nut-Ring & Fitting Plate. SUPER CELL®, SPORTS CELL®, SAVER CELL®





### 1-800-526-5330 www.atlFUELcells.com www.atlinc.com

**ATL Racing Fuel Cells (USA)** Spear Road Industrial Park, Ramsey, NJ 07446-1251 USA Tel: 201-825-1400 Fax: 201-825-1962 email: atl@atlinc.com

**ATL Racing Fuel Cells (UK)** One Patriot Drive, Rooksley Park, Milton Keynes, England MK13-8PU Tel: (0)1908-351700 Fax: (0)1908-351750 email: atl@atlltd.com