## ALCOHOL BLADDER PERFORMANCE COMPARISON



RODIIC

## SALDANA/PYROTECT ALCOHOL BLADDER FACTS

**1)** Do not clean bladder with household cleaning agents.

2) Do not add octane boosters, <u>they will destroy</u> <u>bladder.</u>

**3)** Use 100% alcohol only i.e. methanol, ethanol **(NO E-85)** 

**4)** Top Lube, mix 1 to 220 parts by volume.

**5)** Use 20 inch lbs. torque on top plate.

6) Repairs *<u>not</u>* offered.

**7)** Winterize: Remove fuel, mild soap wash, rinse with water. Dry completely. Close it up. Armorall can be applied. Store in climate-controlled area.



Above Referenced From Document Available @ saldanaracingproducts.com

ATL World Headquarters Aero Tec Laboratories Inc. 45 Spear Road Corporate Park Ramsey, New Jersey 07446-1251 USA Tel: +1-201-825-1400 • Fax: +1-201-825-1962 Email: atl@atlinc.com • Web: atlinc.com



## ALCOHOL BLADDER FACTS

**1)** Use <u>*any*</u> household cleaning liquids except ammonia on both inside & outside of bladder.

**2)** Compatible with <u>most</u> octane boosters: MCMT, MMT, MTBE, BUTANOL and TEL.

**3)** Use Methanol, Ethanol, E85, E-95 or Butanol. <u>*All*</u> are compatible with ATL Sprint type 831-C bladders.

**4)** Top Lube should be premixed 1 *pint* to 27 *gallons* of fuel. (0.5% concentration)

5) Fill-Plate: 15 <u>inch lbs.</u> torque on <u>rubber</u> gasket;
20 <u>inch lbs.</u> for <u>cork</u> gasket.

**6)** ATL bladders <u>are</u> repairable. Repairs require returning bladder to ATL for inspection & factory professional patching. ATL can repair most any ATL cell.

**7)** No winterization required. However, if desired, apply step #1 above, dry thoroughly, store in poly-bag.

8) <u>All</u> aluminum parts fully anodized.

**9)** ATL cells can be offered to meet FIA FT3 and/or SFI 28.2 specifications.

**10)** ATL offers alcohol fuel cells for Sprints, Midgets, Dirt-Mods, Super-Mods, Indy Historics, Asphalt Modifieds, Bonneville L.S.R., Silver Crown, Dirt Late Models & Drag Racers.

## **ATL European Operations**

Aero Tec Laboratories Ltd. ATL Technology Centre, Denbigh Road Bletchley, Milton Keynes, MK1 1DF Tel: +44 (0) 1908-351700 • Fax: +44 (0) 1908-351750 Email: atl@atlltd.com • Web: atlltd.com

